



ACEF-10



21	R03005001203	Power Cord	1
20	R04011000388	Strain Relief	1
19	R03016001148	Thermal Reset	1
18	R03002000159	Thermostat	1
17	R03008000093	Power Switch	1
16	R03004000166	Indicator Light	1
15	R06021000021	Knob	1
14	R06021000024	Dial Plate	1
13	E011301200020	Control Enclosure	1
12	R04010000134	Rubber Ring	1
11	R03011000205	Heating Element	1
10	E010101100005430	Wire Clamp	4
9.1	E011301200015304	Left Tube Clamp	1
9	E011301200016304	Right Tube Clamp	1
8	E0113012000040	Element Cover	1
7	R06001000184	Adjustable Foot	1
6	E0113012000010	Fryer Cabinet	1
5	R18004000028	Oil Pan (10lbs)	1
4	R06018000051	Basket	2
3	R05025000001	Handle Screw	1
2	R04001000048	Cover Handle	1
1	E011301200013430	Pan Cover	1
No.	Part #	Part Name	Qty